

Table: Bron [www.fci.be](http://www.fci.be)  
 0,90 x 0,90 m minimum – 1,20 x 1,20 m maximum.  
 Height: L: 60 cm. - M and S: 35 cm.  
 The table must be stable with a non-slippery surface.  
 An electronic timing device (audible signal after 5 seconds) can be built into the table surface except for an area, 10 cm. wide around the top edges of the table.

Tafel :  
 min.90 x 90cm.-max.120 x 120cm.  
 Hoogte : L=60cm.-M en S = 35cm.  
 Zij moet stabiel zijn en het blad moet voorzien zijn van een antislip materiaal.  
 In het blad kan een elektronisch aftelmechanisme, met na 5 seconden een hoorbaar signaal, gebouwd worden dat gevoelig is over de gehele oppervlakte behalve in een band van 10cm. Breed langs de omtrek.

**Instructions for use:**

The electronic sensor suitable for table of 90 x 90 cm.

- 1 Sensor sheet.
- 2 Anti-skid mat.
- 3 MDF protection sheet.
- 4 Agility table counter control.



**Installation of sensor-mat:**

- Put the mat upside down to the ground.
- Lose the lines.
- Remove the sensor-mat.
- Remove the MDF protection sheet.
- Put the sensor-mat in the middle. Pay attention to! Sensor-site down.
- Put the table upside down on the sensor-mat
- Fasten the lines
- Turn the table and put him on its legs
- Check if the sensor-mat is in the middle of the table
- Correct if necessary by moving the sensor-mat under the anti-skid mat



# Agility Table Counter



**BEWI-techniek**  
[www.bewitechniek.nl](http://www.bewitechniek.nl)

**Control:**

Assemble the counter control by using the elastics to the inside the legs of the table.

Connect the plug of the sensor-mat in the connection on the back of the control.

The remaining cable can put into the tube of the anti-skid mat.

**Operation:**

The counter control can be used at two ways.

1. Connected to the table (its go automatically)
2. By hand. (push the red button when the dog is on the table)



**At activation:**

- 0 Short beep still 5 seconds
- 1 Beep still 4 seconds
- 2 Beep still 3 seconds
- 3 Beep still 2 seconds
- 4 Beep still 1 second
- 5 10 short beeps GO



If the 10 short beeps are hear then the table is leave correct.

By leaving the table too early the GO indication is not to hear.

By leave the table too early you must take the table again and start the complete cycle again.

**Battery indications:**

If the battery is nearly empty you will hear after +/- 10 sec. when a dog left the table several short beeps. This means that the battery is low.

You can quietly finish the competition without the battery to replace.

Sounds there after +/- 10 second double range short beeps then the battery is empty and must replace directly.